



**NOTES**

1. Fence or barrier post tube or PVC pipe to be placed during wall construction
2. Carefully trim geogrid to allow for the fence or barrier post



**BOWERS**  
brothers concrete ltd

The purpose of this drawing is for preliminary design only. This drawing should not be used for final design or construction without the certification of a professional registered engineer. © 2020 BOWERS

<b>TITLE:</b>			<b>A3</b>
<b>Rocklok Fence On Top</b>			
<b>PROJECT No:</b>	<b>DRAWING No:</b>	<b>DATE:</b>	<b>REV:</b>
N/A	Retaining 10	August 2020	Rev.A
<b>DESIGNED BY:</b>			<b>SCALE:</b>
BOWERS BROTHERS CONCRETE LTD			Not to Scale