



**Note:**

1. Control joints must be a maximum of 6 metres apart (see elevations).
2. If there are no openings within 6m of a corner then install a control joint within 3m of the corner.
3. Windows and door openings up to 1.8m width require a control joint in line with only 1 jamb which may be in a "zig zag/sawtooth" line (see elevations).
4. Openings wider than 1.8m should have control joints in line with both jambs (see elevations).

## Bowers Brothers Masonry Veneer Control Joint Alternative Solution

**Dwg. No. BB-51      Dwg. Scale- 1:5**

Technical Support:

Steve Crossland

Steve.c@bowersbrothers.co.nz

[www.bowersbrothers.co.nz](http://www.bowersbrothers.co.nz)

Disclaimer: This is a general detail and is intended as a guide for use of Bowers Brothers Bricks and should not override any consulting engineers recommendations for site specific locations.

Bowers Brothers Concrete Ltd makes no warranty regarding the use of this information with non- Bowers products.